


Service Manual

Stereo Cassette Player

Mini Cassette
RQ-S45




Color
(K)... Black Type

Area		
Country Code	Area	Color
(E)	Continental Europe.	(K)
(EB)	Great Britain.	

※ Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation. "Dolby" and the double-D symbol are trade marks of Dolby Laboratories Licensing Corporation.

AR90 MECHANISM SERIES

■ SPECIFICATIONS

General:
Power Requirement: Battery; 1.5V (one "AA" size battery)
(Panasonic UM-3/R6P, AM3/LR6 or equivalent)
Rechargeable Battery; DC 1.2V with an included Panasonic Rechargeable Battery (RP-BP61SYB) × 1
AC; with optional Panasonic AC adaptor RP-AC11
Power Output: 6mW + 6mW
Input: DC IN; 1.5V (mini jack, )
Output: Headphones; 16Ω (φ3.5)
Dimensions: (W × H × D) 106 × 73.8 × 18.6 mm
Weight: 153 g (with rechargeable battery)

Charger: (E) Input; AC 220V, 50Hz, 4W (RP-BC155EY-0)
(EB) Input; AC 240V, 50Hz, 4W (RP-BC155EYB-0)
Output; DC 1.2V, 350mA
Frequency Response: 15~20,000Hz (with a normal tape)
15~20,000Hz (with a CrO₂ type tape)
15~20,000Hz (with a Metal tape)
Motor: Electrical governor motor
Track System: 4-track 2-channel stereo playback
Tape Speed: 4.8cm/s

Design and specifications are subject to change without notice.









■ CONTENTS

	Page
OPERATING INSTRUCTIONS	2~4
PROCEDURE FOR THE REPLACEMENT OF THE MECHANISM BLOCK	5
PROCEDURES FOR DISASSEMBLY OF THE MAIN PARTS ON THE MECHANISM	6
DISASSEMBLY INSTRUCTIONS	7~9
MEASUREMENTS AND ADJUSTMENTS	10
TERMINAL FUNCTION OF IC	10, 11
HOW TO CHECK OPERATIONS DURING DISASSEMBLY AND SERVICING	12, 13

	Page
SCHEMATIC DIAGRAM	14~16
PRINTED CIRCUIT BOARDS AND WIRING CONNECTION DIAGRAM	17, 18
REPLACEMENT PARTS LIST	19, 20
CABINET PARTS LOCATION	21
MECHANICAL PARTS LOCATION	21
RESISTORS & CAPACITORS	22, 23
PACKING	23

Panasonic

OPERATING INSTRUCTIONS



PRECAUTIONS

- Avoid using or placing this unit near sources of heat. Do not leave it in an automobile exposed to direct sunlight for a long period of time with the doors and windows closed, as this may deform the cabinet.
- When not in use, disconnect the AC adaptor from the AC power outlet.

Precautions for Listening with the Headphones





- Do not play your headset at a high volume. Hearing experts advise against continuous extended play.
- If you experience a ringing in your ears, reduce volume or discontinue use.
- Do not use while operating a motorized vehicle. It may create a traffic hazard and is illegal in many areas.
- You should use extreme caution or temporarily discontinue use in potentially hazardous situations.
- Even if your headset is an open-air type designed to let you hear outside sounds, don't turn up the volume so high that you can't hear what's around you.



Stereo earphones (included)


The right earphone cord is longer than the left and is adjustable for your convenience.

LOCATIONS OF CONTROLS

- ① S-XBS Switch (S-XBS)
- ② Dolby[®] Noise Reduction Switch (DOLBY NR)
- ③ Reverse Mode Selector (REV MODE)
- ④ Hold Switch (HOLD)
- ⑤ Operation/Battery Check Indicator (OPR/BATT)
- ⑥ Push Open Button (PUSH OPEN)
- ⑦ Headphones Jack () 16Ω ϕ 3.5
- ⑧ Volume Control (VOL)
- ⑨ Play/Direction Button (PLAY/DIR  )
- ⑩ Stop Button ()
- ⑪ Fast Forward Button (FF)
- ⑫ Rewind Button (REW)
- ⑬ Rechargeable Battery Cover
- ⑭ Connection Part for Battery Case

Stereo Earphones with remote controller

- ⑮ Slider
When not in use, slide to prevent entanglement of the cord.
 - ⑯ Amenity sound control Switch (ASC)
 - ⑰ Remote Control Button
 - ※ ⑱ Hold Switch (HOLD)
 - ⑲ Volume Control (VOL)
 - ⑳ Clip
- (A) Running Indicator
 (B) Operation Time Indicator
 (C) Amenity Sound Control Switch Indicator
 (D) Remote Control Operation Indicator
 (E) Running Direction Indicator

^{*}Dolby noise reduction manufactured under license from Dolby Laboratories Licensing Corporation.
^{*}"DOLBY" and the double-D symbol  are trademarks of Dolby Laboratories Licensing Corporation.

Optional R6/LR6 Battery Operation (Refer to [B].)

Insert a R6/LR6 battery (Panasonic UM-3 or equivalent, not included) into the Battery Case (included), then attach it to the unit. Make sure that the proper polarity is maintained.

To Prevent Possible Damage to this Unit

- Load new battery with its polarity (+ and -) aligned correctly.
- Do not apply heat to battery or internal short-circuit may occur.
- If this unit is not to be used for a long period of time, or used on AC mains supply, remove the battery and store it in a cool and dry place.
- Remove spent battery immediately.

Notice:

Do not carry the Battery Case in your pocket or bag with the battery installed. It may be possible that a metal object will short-circuit the battery pack and become hot.

To Extend the Operation Time to about 12 Hours...

Install both types of battery (recharged rechargeable battery and optional LR6 alkaline battery) to the unit.

Operation Time Indicator (B)

This function keeps track of operation time that elapses following insertion of battery. When two hours have passed, the mark "●" will appear on the LCD to inform the user. Count is automatically reset when battery is removed.

AC Power Operation (Refer to [C].)

Attach the Battery Case to the unit and connect the optional AC adaptor (RP-AC11) as shown in the figure.

CASSETTE TAPES

This unit is equipped with an auto tape select function; you can use normal, CrO₂ or metal types of tape.

Notes:

- Cassette tapes, both recorded and unrecorded, should not be stored in locations with high temperature, high humidity or direct sunlight. Never place a recorded cassette near a magnetic source, such as a magnet or a TV set as this may affect tape performance.
- Do not use C-120 tapes with this unit because these tapes can easily become broken or stretched if not used with extreme care and may get tangled with the Capstan and Pressure roller.

POWER SOURCE

The Rechargeable Battery and R6/LR6 Battery (not included) are used for the unit operation.

Rechargeable Battery Operation (Refer to [A].)

For its initial use after purchasing or its use after a long time interval (more than three months), make sure to recharge the Rechargeable Battery. Normally 2 hours recharging makes the approximately 3.2 hours tape playback possible.

1. Insert the Rechargeable Battery into the Charger, making sure that the proper polarity is maintained.
2. Plug the Charger into your household AC power outlet.
3. Open the Rechargeable Battery Cover.
4. Insert the charged battery into the unit.

Disconnect the Charger in about 2 hours.

Notes:

- Do not recharge more than 24 hours, otherwise the Rechargeable Battery life may be shortened.
- For its initial use after purchasing or its use after a long time interval, 2 hours recharging may not make normal operation time possible. But the repeat of recharging will recover the normal operation time.
- Use only the included Charger when recharging.
- During recharging, the Charger and Rechargeable Battery may have a little heat. But it is normal.
- Avoid recharging or placing the Rechargeable Battery near sources of heat or in the much humid ambience.
- Do not attempt to recharge R6/LR6 type carbon or alkaline batteries in the Charger.

Rechargeable Battery Life

This Rechargeable Battery can be recharged about 300 times. Over 300 times, its operation time will become shortened. That's time for replacing the Rechargeable Battery (RP-BP62).

When to Recharge the Rechargeable Battery or Replace the Battery

When the battery becomes weak, the Operation/Battery Check Indicator (E) will dim or turn off.


It's time to recharge the Rechargeable Battery or replace the R6/LR6 Battery with new one.

HOLD OPERATION

Setting the Hold Switch (Q) to "HOLD" position will hold the present condition of all controls. This is useful to prevent the unexpected operation. There is a Hold Switch on the main unit (Q) and the Remote Controller (P). In order to operate this unit it is necessary to release the hold condition by operating one of these switches.

※ About the hold switch

Before operating the button, be sure to release the hold state.



AMENITY SOUND CONTROL OPERATION

When the Amenity Sound Control Switch (⑩) is set, the Amenity Sound Control Switch Indicator (Ⓒ) will read "MILD". When this switch is cancelled, the display will read "NOR".
Setting to the "MILD" position will make the more amenity sound possible. Also it will lessen the leaking noisy high sound disturbing the people around you in the train and reduce the strain of listening for a long time.

TAPE PLAYBACK

1. Press the Push Open Button (⑥) to open the cover and insert the cassette.
(Refer to ⑤.)
•After closing the cover, the tape will be wound and the slack will be taken up automatically.
 2. Plug the Stereo Earphones into the Headphones Jack (⑦).
Make sure to install the jack completely so that outer ring is seated into place firmly.
 3. Release the hold condition (④).
 4. Press the Play/Direction Button (③) and adjust the volume.
•The Running Direction Indicator (Ⓔ) will appear.
•The Running Indicator (Ⓐ) will move.
- To stop the tape moving, press the Stop Button (⑤).

Fast Forward and Rewind

This unit allows the tape to fast forward or rewind by simply pressing the Fast Forward (①) or Rewind (②) Button.
To fast forward the tape, press the Fast Forward Button.
To rewind the tape, press the Rewind Button.
•When the tape reaches its end, the tape will automatically stop.

Auto Play

Skip Reverse

During playback, if you press the Fast Forward Button (①), the tape will fast forward to the end, reverse direction, and the playback will start from the beginning of the reverse side automatically.

Rewind Auto Play

During playback, if you press the Rewind Button (②), the tape is rewound and the playback will start from the beginning of the same side automatically.

Manual Reverse

Select the playback side by pressing the Play/Direction Button (③) during playback.
•The Running Direction Indicator (Ⓔ) will change. (FWD or REV).

Auto Reverse

When the tape comes to its end, the auto reverse system functions and the tape direction changes automatically to start playing the opposite side of the tape.

→ : For playback of both sides of the cassette tape once.

Notes:

- Playback will stop when the end of reverse side is reached.
- If playback starts from the reverse side, only that side will be played.

↔ : For continuous playback of both sides of the cassette tape.

Note:

When the cassette compartment cover is opened or after the batteries are replaced, the playback will always start from the forward side.

S-XBS Switch (①)

S-XBS boosts the low frequency range.
You can enjoy the dynamic low sound.
The selection of "MAX" and "MID" to suit your taste is possible.

Dolby Noise Reduction Switch (②)

This unit includes Dolby Noise Reduction which reduces the noise.
Set this switch to "ON" to play back a tape recorded with Dolby Noise Reduction.
For other tapes, set to "OFF".

REMOTE CONTROL OPERATION

The Remote Control Button (⑪) changes the operation of this unit depending on when and how many times it is pressed.

In stop condition

Press once The playback will start.

In playback condition

To stop Press the button once.
To change the tape direction Press and hold the button for more than 1 second.
To fast forward* Press the button twice.
To rewind** Press the button three times.

In fast forward or rewind

To stop the fast forward or rewind and resume playback Press the button once.

*If the tape is forwarded to the end of the tape, the playback will start from the reverse side automatically. (Skip Reverse Function)
**If the tape is rewound to the beginning of the tape, the playback will start from the same side automatically. (Rewind Auto Play Function)

Notes:

- Before using the Remote Controller, be sure to release the hold condition of the controller. [Slide up the Hold Switch (⑩) to release.]
- For volume adjustment, first set the Volume Control (⑨) of the main unit to 5-7.
- When pressing the button twice or three times in succession, press it within one second and at equal intervals.

REMOTE CONTROL OPERATION AND BEEPS

The beep (pi) will be emitted each time the Remote Control Button (⑪) is pressed. Also, confirmation beeps will be emitted after pressing to confirm the proper operation.

Operation	Beep	Confirmation Beep	Function
Press once	Pi	—	Play
(during playback) Press Twice	PiPi	PiPi	Fast Forward (Skip Reverse)
(during playback) Press three times	PiPiPi	PiPiPi	Rewind (Rewind Auto Play)
(during playback) Press and hold for more than one second	Pi	Pi	Change tape direction
(during playback) Press once	Pi	Pi...	Stop

Beeps and Display

When the Remote Control Button is pressed, the unit will beep and the mark "Ⓜ" will appear on the display. (The mark "Ⓜ" will appear after the unit begins playback.)

Beeps-Stereo Function

Depending on the tape side being played, beeps will be emitted from either the right or left earphone.

During playback of forward side (FWD): Right Stereo earphone
During playback of reverse side (REV): Left Stereo earphone

MAINTENANCE (Refer to ⑤.)

- ① Cotton Swab
- ② Pressure Rollers
- ③ Head
- ④ Capstans

The head assembly, Capstans, and Pressure rollers are in constant contact with the tape. If these parts are dirty, the sound quality will be impaired. Periodically, clean these parts.

1. Open the Cassette Compartment cover.
2. The Playback head, Capstans and the Pressure rollers can be seen. Clean them with a Cotton swab.

Notes:

- If the head assembly is extremely dirty, clean it with a soft cloth dampened with a little alcohol.
- Do not bring metal articles or magnetic material, such as a screwdriver, near the head assembly.
- Do not clean the plastic cabinet with benzine or thinner. Clean it with a cloth, dampened in a mild solution of soap and water. Avoid excessive moisture.
- Avoid spray-type insecticides. Some insecticides contain chemicals that could cause cabinet deformation.

■ PROCEDURE FOR THE REPLACEMENT OF THE MECHANISM BLOCK

• How to replace the mechanism block


The mechanism block is supplied without other parts as a semi-assembly. The head block, motor and belt are supplied separately from the mechanism block.

If the mechanism block is exchanged as a replacement assembly, follow the preparation procedure below.

Preparation procedure

Remove the head block, motor and belt from the mechanism to be replaced and replace those parts to the new mechanism block.

(Refer to the "PROCEDURES FOR DISASSEMBLY OF THE MAIN PARTS ON THE MECHANISM".)




※ The adjustment of the mechanism block is unnecessary after replacement.

• How to replace the head block

The head and pinch roller are supplied together in the head block. The pinch roller is also supplied separately.

Preparation procedure

The head block for replacement is not supplied with a holder as shown in the figure below. Therefore, remove the holder from the block to be repaired and mount it to the new head block. Then, proceed to replace the head block. (Refer to "PROCEDURES FOR DISASSEMBLY OF THE MAIN PARTS ON THE MECHANISM".)



※ Head azimuth adjustment is unnecessary.

■ PROCEDURES FOR DISASSEMBLY OF THE MAIN PARTS ON THE MECHANISM


• How to remove the mechanism

Follow the procedures in Ref. Nos. 1~7 in the Disassembly Instructions. (See pages 7, 8.)

※ After replacing the parts, refer to the notes for assembly. (See page 9.)


• How to remove the head block and pinch roller

1. Follow the procedures in Ref. Nos. 1 and 7 in the Disassembly Instructions, remove the rear cabinet and cassette compartment lid. (See pages 7 and 8.)
2. Remove 5 solders (Head FPC). (See Fig. 4.)
3. Remove 2 screws (①, ②) in order to remove the head block. (See Fig. 5.)
4. Remove 2 washers. (See Fig. 6.)
5. Remove 2 springs in order to remove the pinch roller. (See Fig. 7.)




• How to remove the motor and belt

1. Follow the procedures in Ref. Nos. 1~7 in the Disassembly Instructions. (See pages 7, 8.)
2. Remove the washer and motor wheel to remove the belt from the motor pulley. (See Fig. 8.)
3. Remove 2 screws (①, ②) in order to remove the motor. (See Fig. 9.)
4. Remove 2 screws (③, ④) and then the attachment plate to remove the belt. (See Fig. 10.)








• How to attach the belt

1. Attach the belt as shown in the figure. (See Fig. 11.)
2. Mount the attachment plate and secure it with 2 screws. (See Fig. 11.)



DISASSEMBLY INSTRUCTIONS

THIS UNIT CONTAINS' F.P.C. BE CAREFUL NOT CUT OR DAMAGE THE FOIL DURING DISASSEMBLY.

Ref. No. 1	Removal of the bottom cabinet		
Procedure 1			
			
<p>1. Remove the 4 screws (①~④).</p> <p>2. Remove the claw in the direction of the arrow ①, and then remove the battery cover in the direction of the arrow ②.</p>		<p>3. Remove the bottom cabinet in the direction of the arrow ④ while pushing the rechargeable battery (+) terminal in the direction of the arrow ③.</p>	
Ref. No. 2	Removal of the side cabinet	Ref. No. 3	
Procedure 1→2		Procedure 1→3	
		<p>1. Remove the 3 screws (①~③).</p> <p>2. Remove 5 solders of the head FPC.</p> <p>3. Remove 4 solders on the motor terminal.</p> <p>4. Remove 2 solders on the solenoid terminal.</p> <p>5. Remove 1 solder on the rechargeable battery (-) terminal.</p> <p>6. Remove 11 solders on the connection of operation switch P.C.B. and main P.C.B.</p> <p>Note: When the main P.C.B. is removed, the rechargeable battery (+) terminal will also be removed.</p>	
Ref. No. 4	Removal of the operation switch P.C.B.		
Procedure 1→2→3→4			
			
<p>• Remove the 1 screw (①).</p>			







Ref. No. 5	Removal of the middle cabinet	Ref. No. 6	Removal of the link angle ass'y
Procedure 1→2→3 →4→5		Procedure 1→2→3 →4→5→6	
			
Ref. No. 7	Removal of the cassette lid	Ref. No. 8	Removal of the knobs
Procedure 7		Procedure 1→2→8	
			
Ref. No. 9	Removal of the operation button and jack piece	<p>■ The operation buttons and jack piece are fixed by the insulation sheet. Remove the insulation sheet to detach the operation buttons and jack piece as follows:</p> <p>1. Pick up the notch of the insulation sheet between your fingers (see Fig. 1).</p> <p>2. Remove the insulation sheet slowly and carefully as shown in Fig. 2.</p>	
Procedure 1→9			
			


Fig. 1

Fig. 2

Notes for assembly


■ How to install the middle cabinet

- Engage hole ① of the link angle ass'y in the rib of the middle cabinet.




■ Note for attaching of the insulation sheet

- Fit an end of the insulation sheet to the battery compartment cover side, and past the sheet properly without any fold or wrinkle.




■ How to install the main P.C.B.

- Engage the switch in the lever of the mechanism.
- Insert the rechargeable battery (+) terminal in the shaft.



■ How to install the knobs

- Engage the knobs in the boss of switches.



MEASUREMENTS AND ADJUSTMENTS

ADJUSTMENT INSTRUCTIONS

READ CAREFULLY BEFORE ATTEMPTING ADJUSTMENT

1. Set volume control to maximum.
2. Set Dolby NR Switch to OFF.
3. Set ASC switch to NORMAL.
4. Set S-XBS Switch to OFF.
5. Set hold switch to OFF.
6. Set power source voltage to 1.5V DC.
7. Output of signal generator should not be higher than necessary to obtain an output reading.

CONTROL POSITIONS AND EQUIPMENT USED

1. Frequency counter

TAPE SECTION

ITEM	TEST TAPE	MEASUREMENT POINT	ADJUSTMENT POINT	PROCEDURE
Tape speed	QZZCWAT (3kHz, -10dB)	Connect the frequency counter to Headphones jack (16Ω) (Refer to Fig. 1)	VR2 (Refer to Fig. 2 or 3)	Playback the central part of the tape and adjust VR2 so that the tape speed is as follows. Forward: 2960 ± 10 Hz Reverse: 2940~3050 Hz Make sure that the frequency range is within ± 60 Hz for between "Forward" and "Reverse" mode.

Note: The playback head is supplied on the head arm assembly. (See the Mechanism parts location on page 21.)
The assembly requires no adjustment.




Fig. 1





Fig. 2



Case of bottom cabinet is removed

Fig. 3

TERMINAL FUNCTION OF IC

IC6: M34210M2124G (MECHANISM CONTROL)

Terminal No.	Terminal Name	I/O	Function
1	NC	—	—
2	NC	—	—
3	CE	I	Connected to power supply.
4	RESET	I	Inputs the reset signal.
5	V _{DD}	—	Power supply terminal
6	TPS IN	—	Inputs the TPS control signal. Unused on this unit.
7	T.END	I	Inputs the signal for the detection of tape rotation. When the pulse signal is input: The current mode remains set as the tape is rotating. No pulse signal: Stops or starts reverse playback as the tape has stopped rotating (ie, reached the end).
8	C	—	Condenser external terminal. Unused on this unit.
9	LED F	O	Outputs the LED lit signal that indicates that the tape is running. Outputs the head switching signal.
10	LED R	O	Outputs the LED lit signal that indicates that the tape is running.
11	REC	O	Outputs the recording LED lit signal.
12	TU. ON	O	Outputs the signal for turning ON/OFF the power on the DTS controller.
13	NC	—	—
14	POW	O	Outputs the power switching signal (POWER SW).

Terminal No.	Terminal Name	I/O	Function
15	MOTOR	O	Output the motor drive signal (MOTOR ON).
16	M-CCW	O	Outputs the counter clockwise motor control signal.
17	M-SPEED	O	Outputs the motor speed UP signal.
18	CN V _{SS}	—	For ground connection
19	V _{SS}	—	For ground connection
20	MUTE	O	Outputs the AMP muting signal. (Set to ON during muting.)
21	P-SOL	O	Outputs the solenoid drive signal for playback.
22	R-SOL	—	Outputs the solenoid drive signal for recording. Unused on this unit.
23	REC MUTE	—	Outputs the recording muting signal. Unused on this unit.
24	TPS	O	Outputs the TPS signal. For ground connection.
25	NC	—	—
26	FF	O	Outputs mechanism operation (FF) signal.
27	REW	O	Outputs the mechanism operation (REW) signal.
28	BEEP F	O	Generates the beep sound when the unit is controlled remotely.
29	PLAY-RSW	I	Inputs the mechanism status detection signal (REV PLAY). At low: ON At high: OFF
30	PLAY-FSW	I	Inputs the mechanism status detection signal (FWD PLAY). At low: ON At high: OFF
31	BEEP R	I	Generates the beep sound when the unit is controlled remotely.
32	DIS DATA	—	Unused on this unit. For ground connection.

Terminal No.	Terminal Name	I/O	Function
33	CE IN	I	Unused on this unit. For ground connection.
34	RADIO	I	Inputs the FUNCTION SW RADIO signal.
35	DATA OUT	O	Unused on this unit. For ground connection.
36	REMOTE	I	Inputs the signal for remote control.
37	NC	—	Connected to "REV MODE" terminal.
38	STOP	I	Inputs the mechanism operation signal (STOP). When a low pulse is input: Switches to the stop mode.
39	PLAY	I	Inputs the mechanism operation signal (PLAY). When a low pulse is input: Switches to the play mode.
40	FF	I	Inputs the mechanism operation (FF) signal. When a low pulse is input: Switches to the FF mode.
41	REW	I	Inputs the mechanism operation (REW) signal. When a low pulse is input: Switches to the REW mode.
42	OPEN	I	Inputs the signal that detects whether the cassette tape is inserted. At low: ON (close); the tape is inserted. At high: OFF (open); the tape is not inserted.
43	REV MODE	I	Inputs the reverse mode switching signal. At low: ⤴ mode At high: ⤵ mode
44	GND	—	For ground connection
45	OMR	I	Inputs the OMR SW signal (ONCE MORE SW).
46	HOLD	I	Inputs the HOLD SW signal. At low: ON (HOLD) At high: OFF
47	Xout	O	Outputs the clock signal.
48	Xin	I	Inputs the clock signal.

■ HOW TO CHECK OPERATIONS DURING DISASSEMBLY AND SERVICING

1. Cassette section

• Check operations during disassembly following the steps.

- 1) Set the condition as shown in Fig. 1 in accordance with Disassembly Instructions. (DO NOT remove the solders on the head FPC.)
- 2) Connect the PCB and motor with the extension cord (RFKZ0002).
- 3) Short the short land with a soldering and then short-circuit them.

• Short the short land ① for Power supply of AMP ON.

• Short the short land ② for Power supply of motor ON.

• Short the short land ③ for Microcomputer reset.

Note: See next page for the points to be short-circuited.

- 4) Connect the rechargeable battery (+) terminal and the rechargeable battery (—) terminal foil to the power source (DC 1.5V) with a lead wire. (Fig. 1)

- 5) Connect the rechargeable battery (—) terminal foil and the rechargeable battery (—) terminal with a lead wire (mechanism earth).

- 6) Manually operate the plunger arm when checking the PLAY/STOP operation.

• Manually pulling the plunger arm once sets the FWD mode; twice, REV; and, three times, STOP.

Notes: • Operate the plunger arm manually. Even if the operation buttons are pressed, the plunger will not be actuated.

• Even if the mechanism unit is switched to the FWD mode in Step 6, the head change-over switch (IC1) will remain in the REV position, so set the REV mode to check the audio.

Before checking the operation problems and adjustments, be sure to release the hold state.

(Hold switch (S2): "OFF")

• After checking, unsolder the short land ①, ② and ③.





Fig. 1


• Short SCHEMAT

Short the s (Gauge No.



PRINTED

RECHA BATTE (RP-BI



HOW TO CHECK OPERATIONS DURING DISASSEMBLY AND SERVICING

1. Cassette section

- Check operations during disassembly following the steps.
 - Set the condition as shown in Fig. 1 in accordance with Disassembly Instructions. (DO NOT remove the solders on the head FPC.)
 - Connect the PCB and motor with the extension cord (RFKZ0002).
 - Short the short land with a soldering and then short-circuit them.
 - Short the short land ① for Power supply of AMP ON.
 - Short the short land ② for Power supply of motor ON.
 - Short the short land ③ for Microcomputer reset.
- Note:** See next page for the points to be short-circuited.
- Connect the rechargeable battery (+) terminal and the rechargeable battery (-) terminal foil to the power source (DC 1.5V) with a lead wire. (Fig. 1)
 - Connect the rechargeable battery (-) terminal foil and the rechargeable battery (-) terminal with a lead wire (mechanism earth).
 - Manually operate the plunger arm when checking the PLAY/STOP operation.
 - Manually pulling the plunger arm once sets the FWD mode; twice, REV; and, three times, STOP.
- Notes:** • Operate the plunger arm manually. Even if the operation buttons are pressed, the plunger will not be actuated.
- Even if the mechanism unit is switched to the FWD mode in Step 6, the head change-over switch (IC1) will remain in the REV position, so set the REV mode to check the audio. Before checking the operation problems and adjustments, be sure to release the hold state. (Hold switch (S2): "OFF")
 - After checking, unsolder the short land ①, ② and ③.






Fig. 1

• Short points

SCHEMATIC DIAGRAM (A Main Circuit)



PRINTED CIRCUIT BOARD (A Main P.C.B.)



SCHEMATIC DIAGRAM


(See parts list on pages 19, 22, 23.)

Notes:


- S1 : FWD/REV switch in "FWD" position. (F...FWD, R...REV)
- S2 : Hold switch in "OFF" position.
- S3 : Reverse mode selector switch in " " position.
- S4 : Rewind switch in "OFF" position.
- S5 : Fast forward switch in "OFF" position.
- S6 : Stop switch in "OFF" position.
- S7 : Play/direction switch in "OFF" position.
- S8-1 : Leaf (open/close) switch in "OFF" position.
- S8-2 : Leaf (metal/normal) switch in "OFF" position.
- S9 : Dolby NR switch in "OFF" position.
- S10 : S-XBS switch in "OFF" position.
- VR1-1, VR1-2 : Volume control VR.
- VR2 : Tape speed adjustment VR.
- DC voltage measurements are taken with electronics voltmeter from negative terminal of battery. No mark...Playback
- Battery current (Tape)...170~185mA (VR: MAX)
- This schematic diagram may be modified at any time with the development of new technology.

→ : PLAYBACK SIGNAL
→ : ⊕ B LINE

A
B
C
D
E
F
G



A MAIN CIRCUIT



— 16 —

REPLACEMENT PARTS LIST

Notes : * Important safety notice:
Components identified by Δ mark have special characteristics important for safety. When replacing any of these components use only manufacturer's specified parts.
* The parenthesized indications in the Remarks columns specify the areas. (Refer to the cover page for area.)
Parts without these indications can be used for all areas.


Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		INTEGRATED CIRCUIT(S)					
IC1	TA7795FNEL	IC, PRE AMP		Z1	GP2S27T6	COMPONENT COMBINATION(S)	
IC2	TA7793FNEL	IC, DOLBY NR				COIL(S)	
IC4	TA8157FNEL	IC, S-XBS/POWER AMP		L4	RLQU100KT-W	COIL	
IC5	AN6628FAP	IC, MOTOR DRIVE				TRANSFORMER(S)	
IC6	M34210M2124G	IC, MICRO COMPUTER(MECH)					
		TRANSISTOR(S)		T1	RL09U010T-M	TRANSFORMER	
						OSCILLATOR(S)	
Q1	2SB815B7TW	TRANSISTOR					
Q2	RVTD1A123JUW	TRANSISTOR		X1	RSXD32K7F03	OSCILLATOR	
Q3	2SD1328STW	TRANSISTOR				SWITCH(ES)	
Q4	2SD1819STW	TRANSISTOR					
Q5	2SB1218STW	TRANSISTOR					
Q6	2SD1819STW	TRANSISTOR		S1	RSS2A002-A	SW, MECHANISM DET. FWD/REV	
Q10	UN5116TW	TRANSISTOR		S2	RSS2A003-A	SW, HOLD	
Q11	XP1501TW	TRANSISTOR		S3	RSS2A003-A	SW, REV MODE	
Q12	2SD1328STW	TRANSISTOR		S4	EVQPA101K	SW, REW	
Q13	RVTFMA5TW	TRANSISTOR		S5	EVQPA101K	SW, FF	
Q17	RVTD1A123JUW	TRANSISTOR		S6	EVQPA101K	SW, STOP	
Q19	2SD1819STW	TRANSISTOR		S7	EVQPA101K	SW, PLAY/DIR	
Q20	UN5210TW	TRANSISTOR		S8	RSH1B001-6U	SW, LEAF	
Q21	2SB1218STW	TRANSISTOR		S9	RSS2A003-A	SW, DOLBY NR	
Q22	XN1210TW	TRANSISTOR		S10	RSS3A001-A	SW, S-XBS	
Q23	2SD1819STW	TRANSISTOR					
Q24-26	2SB1218STW	TRANSISTOR					
Q27	2SK1228TW	TRANSISTOR				JACK	
Q28	RVTFMG6	TRANSISTOR					
Q29	UN5216-Q	TRANSISTOR		J1	RJJ36T01-C	HEADPHONES JACK	
Q30, 31	2SD1819STW	TRANSISTOR					
Q32, 33	UN5216-Q	TRANSISTOR					
		DIODE(S)					
D1	MA720TW	DIODE					
D2	MA713TWRA	DIODE					
D3	MA110TW	DIODE					
D4	LN1261CTR	L. E. D.					
		VARIABLE RESISTOR(S)					
VR1	EVUTOGA05A54	V. R, VOLUME CONTROL					
VR2	EVM3SSX50B13	V. R, TAPE SPEED ADJ.					
		COMPONENT COMBINATION(S)					

Ref. No.	Part No.	Part Name & Description	Remarks	Ref. No.	Part No.	Part Name & Description	Remarks
		CABINET AND CHASSIS		108C	RHD14006	SCREW	
						PACKING MATERIAL	
2	RHD14008-K	SCREW					
4	RHQ0003-K	SCREW		P1	RPK0256	VANITY CASE	
5	RHE5119ZA	SCREW		P2	RPN0346-3	ACCESSORIES TRAY	
6	RHQ0021-K	SCREW		P3	RPN0347-1	SET TRAY	
7	RKMD034-K	BATTERY COVER		P4	RPQ0134	ACCESSORIES BOX	
8	XQN14+CJ3FZ	SCREW		P5	RPF0048-1	PROTECTION BAG(F. B.)	
9	RYF0114-K	CASSETTE LID ASS'Y		P6	RPH0018-2	PROTECTION SHEET	
9A	RHE5097ZA	SCREW		P7	RPK0101	HARD CASE	
9B	RXMD025	LINK ANGLE ASS'Y				ACCESSORIES	
10	RYKD193-S	MIDDLE CABINET ASS'Y					
11	RYKD192B-K	BOTTOM CABINET ASS'Y		A1	RQT0877-E	INSTRUCTION MANUAL	
11A	RGPO174-S1	ORNAMENT		A2	RFA0105-K	BATTERY CASE	
11B	RGU0478-K	OPERATION BUTTON		A3	RFEV103P-KS	STEREO EARPHONES	
11C	RKMD150B-K	BOTTOM CABINET		A4	RP-BP62EY	RECHARGEABLE BATTERY	Δ
11D	RMR0366-K	JACK PIECE		A5	RP-BC155EY-0	BATTERY CHARGER	Δ (E)
11E	RMZ0124	SHEET		A5	RP-BC155EY-A	BATTERY CHARGER	Δ (EB)
12	RGU0479-H	BUTTON, OPEN		A6	RFC0006	CARRYING CASE	
13	RGV0066-H	KNOB, S-XBS/DOLBY HOLD		A7	RQA0013A	WARRANTY CARD	
14	RKQ0073-S	SIDE CABINET		A8	RQCB0169	SERVICENTER LIST	
15	RJC99003-2	RECHARGEABLE BATTERY(+)				<PRINTED CIRCUIT BOARD ASS'Y>	
16	RJC99004-2	RECHARGEABLE BATTERY(-)					
18	RJH9201	TERMINAL					
19	RJB0573A-1	OPERATION SWITCH P. C. B.					
20	RHQ0013	SCREW		PCB1	REP0927	MAIN P. C. B. /	(NLA)
21	RKU0034	CAM GEAR CAP				OPERATION SWITCH P. C. B.	
22	RJR0012	BATTERY SHAFT					
		MECHANISM PARTS					
101	HPX-26NB1C	MOTOR					
102	XQS14+A18FZ	SCREW					
103	RDV0016	BELT					
104	RXQ0006-1	HEAD BLOCK ASS'Y					
104A	RNW1012A	WASHER					
104B	RME0004-1	PINCH ROLLER SPRING(L)					
104C	RME0005	PINCH ROLLER SPRING(R)					
104D	RXL0004-1	PINCH ROLLER ARM(L)					
104E	RXL0005	PINCH ROLLER ARM(R)					
105	RMA0023	HOLDER(R)					
106	RHE5147ZA	SCREW					
107	RHW42002	WASHER					
108	RFKRQS11E	HEAD BLOCK ASS'Y					
108A	RMQ0011	ANGLE(L)					
108B	RMQ0012	ANGLE(R)					

Note: Printed circuit board assembly with mark (NLA) is no longer available after discontinuation of the product.

Ref. No.	Part No.	Values & Remarks						
C205	ECUV1C105ZFN	16V 1U						
C206	ECUV1H332MBV	50V 3300P						
C207	ECUV1E822MBV	25V 8200P						
C208	ECUV1E103MBV	25V 0.01U						
C209	ECUV1C105ZFN	16V 1U						
C210	ECUV1C474ZFN	16V 0.47U						
C215	ECUV1C473MBN	16V 0.047U						
C218, 219	ECUV1C105ZFN	16V 1U						
C220	ECUV1H102MBV	50V 1000P						
C221	ECUV1E103KBV	25V 0.01U						
C222	RCSX1AA105LE	10V 1U						
C226	ECUV1H222MBV	50V 2200P						

PACKING





MECHANISM BLOCK ASS'Y

HEAD BLOCK ASS'Y

101, 102, 103, 104, 105, 106, 107, 108, 108A, 108B, 108C, 104A, 104B, 104C, 104D, 104E

— 21 —

RESISTORS & CAPACITORS

Notes : * Capacity valuse are in microfarads (uF) unless specified otherwise, P=Pico-farads (pF) F=Farads (F)
* Resistance values are in ohms, unless specified otherwise, 1K=1,000 (OHM) , 1M=1,000k (OHM)

Ref.No.	Part No.	Values & Remarks	Ref.No.	Part No.	Values & Remarks	Ref.No.	Part No.	Values & Remarks
		RESISTORS	R85	ERJ3GEYJ155V	1/16W 1.5M	C7	RCSX0EY156LE	2.5V 15U
			R89	ERJ3GEYJ104V	1/16W 100K	C9	RCSX0EY156LE	2.5V 15U
			R90	ERJ3GEYJ472V	1/16W 4.7K	C10	RCST0GY475LE	4V 4.7U
R2	ERJ3GEYJ104V	1/16W 100K	R91	ERJ3GEYJ272V	1/16W 2.7K	C11	RCSX0EA475LE	2.5V 4.7U
R8	ERJ3GEYJ183V	1/16W 18K	R92	ERJ3GEYJ123V	1/16W 12K	C13	ECUV1C104ZFN	16V 0.1U
R10	ERJ3GEYJ104V	1/16W 100K	R93	ERJ3GEYJ332V	1/16W 3.3K	C14	ECA0DV221FZ	2V 220U
R11	ERJ3GEYJ154V	1/16W 150K	R94	ERJ3GEYJ682V	1/16W 6.8K	C15	RCSX0GA335LE	4V 3.3U
R12	ERJ3GEYJ47V	1/16W 4.7	R95	RRSL25J122U	1/8W 1.2K	C16	RCSX1AA105LE	10V 1U
R14	ERJ3GEYJ102V	1/16W 1K	R96	ERJ3GEYJ103V	1/16W 10K	C17	ECUV1C105ZFN	16V 1U
R15	ERJ3GEYJ270V	1/16W 27	R97	ERJ3GEYJ821V	1/16W 820	C18	RCSX0GA335LE	4V 3.3U
R16	ERJ3GEYD472V	1/16W 4.7K	R98	ERJ3GEYJ681V	1/16W 680	C19	RCSX1AA105LE	10V 1U
R17	ERJ3GEYD132V	1/16W 1.3K	R100	ERJ3GEYJ393V	1/16W 39K	C20	RCSX1DA474LE	20V 0.47U
R24	ERJ3GEYJ563V	1/16W 56K	R101	ERJ3GEYJ474V	1/16W 470K	C21	ECUV1C105ZFN	16V 1U
R25	ERJ3GEYJ393V	1/16W 39K	R102	ERJ3GEYJ471V	1/16W 470	C22	ECUV1H181KV	50V 180P
R26	ERJ3GEYJ101V	1/16W 100	R103	ERJ3GEYJ183V	1/16W 18K	C23	ECUV1H222MBV	50V 2200P
R29	MCR03PZHJ561	1/16W 560	R104	ERJ3GEYJ392V	1/16W 3.9K	C24	RCST0JY335LE	6.3V 3.3U
R30	ERJ3GEYJ514V	1/16W 510K	R105	ERJ3GEYJ272V	1/16W 2.7K	C25-27	ECUV1C473KBN	16V 0.047U
R31	ERJ3GEYJ474V	1/16W 470K	R107, 108	ERJ3GEYJ333V	1/16W 33K	C28	ECUV1C224MBM	16V 0.22U
R32	EXBV4V224J	1/16W 220K	R109	ERJ3GEYJ133V	1/16W 13K	C29	RCSX1AA105LE	10V 1U
R33	ERJ3GEYJ474V	1/16W 470K	R110	ERJ3GEYJ394V	1/16W 390K	C30	ECUV1C224MBM	16V 0.22U
R34	ERJ3GEYJ224V	1/16W 220K	R118	ERJ3GEYJ122V	1/16W 1.2K	C31	RCST1CY105LE	16V 1U
R35	EXBV4V224J	1/16W 220K	R120	ERJ3GEYJ102V	1/16W 1K	C32	ECUV1H050DCV	50V 5P
R36	EXBV4V472J	1/16W 4.7K	R122	ERJ3GEYJ152V	1/16W 1.5K	C33	ECUV1H150KCV	50V 15P
R38	EXBV4V224J	1/16W 220K	R123	ERJ3GEYJ8R2V	1/16W 8.2	C34	ECUV1C104ZFN	16V 0.1U
R40	EXBV4V224J	1/16W 220K	R125	ERJ3GEYJ101V	1/16W 100	C36	ECUV1C104ZFN	16V 0.1U
R42	EXBV4V474J	1/16W 470K	R126	ERJ3GEYJ223V	1/16W 22K	C37, 38	ECUV1E103MBV	25V 0.01U
R43	ERJ3GEYJ681V	1/16W 680	R127	ERJ3GEYJ682V	1/16W 6.8K	C39, 40	ECUV1H101KV	50V 100P
R47	ERJ3GEYK106V	1/16W 10M	R200	ERJ3GEYJ393V	1/16W 39K	C50-52	ECUV1E104ZFN	25V 0.1U
R48	ERJ3GEYJ823V	1/16W 82K	R201	ERJ3GEYJ474V	1/16W 470K	C59	ECUV1C105ZFN	16V 1U
R49	ERJ3GEYJ154V	1/16W 150K	R202	ERJ3GEYJ471V	1/16W 470	C100, 101	ECUV1H681KBV	50V 680P
R50	ERJ3GEYJ124V	1/16W 120K	R203	ERJ3GEYJ183V	1/16W 18K	C102	RCSX0EY156LE	2.5V 15U
R51	ERJ3GEYJ104V	1/16W 100K	R204	ERJ3GEYJ392V	1/16W 3.9K	C103	ECUV1E822KBV	25V 8200P
R52	ERJ6GEYF564V	1/10W 560K	R205	ERJ3GEYJ272V	1/16W 2.7K	C104	ECUV1C183MBV	16V 0.018U
R53	ERJ6GEYF394V	1/10W 390K	R207, 208	ERJ3GEYJ333V	1/16W 33K	C105	ECUV1C105ZFN	16V 1U
R59	ERJ3GEYJ222V	1/16W 2.2K	R209	ERJ3GEYJ133V	1/16W 13K	C106	ECUV1H332MBV	50V 3300P
R62	ERJ3GEYJ392V	1/16W 3.9K	R210	ERJ3GEYJ394V	1/16W 390K	C107	ECUV1E822MBV	25V 8200P
R63	ERJ3GEYJ183V	1/16W 18K	R218	ERJ3GEYJ122V	1/16W 1.2K	C108	ECUV1E103MBV	25V 0.01U
R64	ERJ3GEYJ124V	1/16W 120K	R220	ERJ3GEYJ102V	1/16W 1K	C109	ECUV1C105ZFN	16V 1U
R65	ERJ3GEYJ334V	1/16W 330K	R222	ERJ3GEYJ152V	1/16W 1.5K	C110	ECUV1C474ZFN	16V 0.47U
R66	ERJ3GEYJ224V	1/16W 220K	R223	ERJ3GEYJ8R2V	1/16W 8.2	C115	ECUV1C473MBN	16V 0.047U
R67	ERJ3GEYJ104V	1/16W 100K	R225	ERJ3GEYJ101V	1/16W 100	C118, 119	ECUV1C105ZFN	16V 1U
R68, 69	ERJ3GEYJ224V	1/16W 220K	R226	ERJ3GEYJ223V	1/16W 22K	C120	ECUV1H102MBV	50V 1000P
R70	ERJ3GEYJ562V	1/16W 5.6K	R227	ERJ3GEYJ682V	1/16W 6.8K	C121	ECUV1E103KBV	25V 0.01U
R71	ERJ3GEYJ102V	1/16W 1K			CAPACITORS	C122	RCSX1AA105LE	10V 1U
R72	ERJ3GEYJ474V	1/16W 470K				C126	ECUV1H222MBV	50V 2200P
R73	ERJ3GEYJ334V	1/16W 330K				C200, 201	ECUV1H681KBV	50V 680P
R74	ERJ3GEYJ154V	1/16W 150K	C1	ECUV1H681KBV	50V 680P	C202	RCSX0EY156LE	2.5V 15U
R75	ERJ3GEYJ474V	1/16W 470K	C2	RCSX0EY156LE	2.5V 15U	C203	ECUV1E822KBV	25V 8200P
R76	ERJ3GEYJ824V	1/16W 820K	C5	RCSX0EY156LE	2.5V 15U	C204	ECUV1C183MBV	16V 0.018U